

MIDI Note	Standard 1-3	Room	Power	Electronic	808/909	Dance	Jazz	Brush	Orchestra	SFX
D#0	High Q	High Q	High Q	High Q	High Q	High Q	High Q	High Q	Closed Hi-Hat	-
E0	Slap	Slap	Slap	Slap	Slap	Slap	Slap	Slap	Pedal Hi-Hat	-
F0	Scratch Push	Scratch Push	Scratch Push	Scratch Push	Scratch Push	Scratch Push	Scratch Push	Scratch Push	Open Hi-Hat	-
F#0	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Pull	Ride Cymbal	-
G0	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	-
G#0	Square Click	Square Click	Square Click	Square Click	Square Click	Square Click	Square Click	Square Click	Square Click	-
A0	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click	-
A#0	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	-
B0	Kick Drum 2	Kick Drum 2	Power Kick 2	Kick Drum 2	808 Bass Drum	Kick Drum 2	Kick Drum 2	Kick Drum 2	Kick Drum 2	-
C1	Kick Drum 1	Room Kick	Power Kick 1	Elec BD	909 Bass Drum	Dance Kick	Jazz Kick	Jazz Kick	Concert BD 1	-
C#1	Side Stick	Side Stick	Side Stick	Side Stick	808 Rim Shot	Side Stick	Side Stick	Side Stick	Side Stick	-
D1	Snare Drum 1	Room Snare 1	Power Snare 1	Elec SD	808 Snare Drum	Dance Snare	Jazz Snare	Brush Tap	Concert SD	-
D#1	Hand Clap	Hand Clap	Hand Clap	Elec Hand Clap	909 Hand Clap	Elec Hand Clap	Hand Clap	Brush Slap	Castanets	High Q
E1	Snare Drum 2	Room Snare 2	Power Snare 2	Gated SD	909 Snare Drum	909 Snare Drum	Brushed Snare	Brush Swirl	Concert SD	Slap
F1	Low Tom 2	Room Low Tom 2	Room Low Tom 2	Elec Low Tom 2	808 Low Tom 2	Elec Low Tom 2	Low Tom 2	Brush Low Tom 2	Timpani F	Scratch Push
F#1	Closed Hi-Hat	Room Closed Hat	Power Closed Hat	Elec Closed Hat	808 Closed Hat	Elec Closed Hat	Closed Hi-Hat	Closed Hi-Hat	Timpani F#	Scratch Pull
G1	Low Tom 1	Room Low Tom 1	Room Low Tom 1	Elec Low Tom 1	808 Low Tom 1	Elec Low Tom 1	Low Tom 1	Brush Low Tom 1	Timpani G	Sticks
G#1	Pedal Hi-Hat	Room Pedal Hat	Power Pedal Hat	Elec Pedal Hat	808 Closed Hat	Elec Pedal Hat	Pedal Hi-Hat	Pedal Hi-Hat	Timpani G#	Square Click
A1	Mid Tom 2	Room Mid Tom 2	Room Mid Tom 2	Elec Mid Tom 2	808 Mid Tom 2	Elec Mid Tom 2	Mid Tom 2	Brush Mid Tom 2	Timpani A	Metronome Click
A#1	Open Hi-Hat	Room Open Hat	Power Open Hat	Elec Open Hat	808 Open Hat	Elec Open Hat	Open Hi-Hat	Open Hi-Hat	Timpani A#	Metronome Bell
B1	Mid Tom 1	Room Mid Tom 1	Room Mid Tom 1	Elec Mid Tom 1	808 Mid Tom 1	Elec Mid Tom 1	Mid Tom 1	Brush Mid Tom 1	Timpani B	Guitar Sliding Finger
C2	High Tom 2	Room Hi Tom 2	Room Hi Tom 2	Elec Hi Tom 2	808 Hi Tom 2	Elec Hi Tom 2	High Tom 2	Brush High Tom 2	Timpani c	Guitar Cut Noise Down
C#2	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	808 Crash 1	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	Timpani c#	Guitar Cut Noise Up
D2	High Tom 1	Room Hi Tom 1	Room Hi Tom 1	Elec Hi Tom 1	808 Hi Tom 1	Elec High Tom 1	High Tom 1	Brush High Tom 1	Timpani d	Double Bass String Slap
D#2	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	808 Ride Cymbal	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Timpani d#	Flute Key click
E2	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Reverse Cymbal	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Timpani e	Laughing
F2	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Timpani f	Screaming
F#2	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Punch
G2	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Heart Beat
G#2	Cowbell	Cowbell	Cowbell	Cowbell	808 Cowbell	Cowbell	Cowbell	Cowbell	Cowbell	Footsteps 1
A2	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	808 Crash 2	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	Concert Cymbal 2	Footsteps 2
A#2	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Applause
B2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	Concert Cymbal 1	Door Creaking
C3	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo	Door
C#3	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Scratch
D3	Mute High Conga	Mute High Conga	Mute High Conga	Mute High Conga	808 High Conga	Mute High Conga	Mute High Conga	Mute High Conga	Mute High Conga	Windchime
D#3	Open High Conga	Open High Conga	Open High Conga	Open High Conga	808 Mid Conga	Open High Conga	Open High Conga	Open High Conga	Open High Conga	Car-Engine
E3	Low Conga	Low Conga	Low Conga	Low Conga	808 Low Conga	Low Conga	Low Conga	Low Conga	Low Conga	Car-Stop
F3	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	Car-Pass
F#3	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Car-Crash
G3	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo	Siren
G#3	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Train
A3	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Jetplane
A#3	Maracas	Maracas	Maracas	Maracas	Maracas	Maracas	Maracas	Maracas	Maracas	Helicopter
B3	Short Hi Whistle	Short Hi Whistle	Short Hi Whistle	Short Hi Whistle	Short Hi Whistle	Short Hi Whistle	Short Hi Whistle	Short Hi Whistle	Short Hi Whistle	Starship
C4	Long Low Whistle	Long Low Whistle	Long Low Whistle	Long Low Whistle	Long Low Whistle	Long Low Whistle	Long Low Whistle	Long Low Whistle	Long Low Whistle	Gun Shot
C#4	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Machine Gun
D4	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Lasergun
D#4	Claves	Claves	Claves	Claves	Claves	Claves	Claves	Claves	Claves	Explosion
E4	High Wood Block	High Wood Block	High Wood Block	High Wood Block	High Wood Block	High Wood Block	High Wood Block	High Wood Block	High Wood Block	Dog
F4	Low Wood Block	Low Wood Block	Low Wood Block	Low Wood Block	Low Wood Block	Low Wood Block	Low Wood Block	Low Wood Block	Low Wood Block	Horse-Gallop
F#4	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Birds
G4	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Rain
G#4	Mute Triangle	Mute Triangle	Mute Triangle	Mute Triangle	Mute Triangle	Mute Triangle	Mute Triangle	Mute Triangle	Mute Triangle	Thunder
A4	Open Triangle	Open Triangle	Open Triangle	Open Triangle	Open Triangle	Open Triangle	Open Triangle	Open Triangle	Open Triangle	Wind
A#4	Shaker	Shaker	Shaker	Shaker	Shaker	Shaker	Shaker	Shaker	Shaker	Seashore
B4	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Stream
C5	Belltree	Belltree	Belltree	Belltree	Belltree	Belltree	Belltree	Belltree	Belltree	Bubble
C#5	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	-
D5	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	-
D#5	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	-
E5	-	-	-	-	-	-	-	-	Applause	-